# Nondestructive Testing to Better Define Repair Quantities

Brian Pailes, PhD, PE, NACE CP-4

**Principal Engineer** 

**Vector Corrosion Services** 



### **Issues Facing Owners**

- How to properly determine repair quantities?
- Sounding and visual inspections are known to underestimate true repair area
- Impacts of underestimating repair quantities
  - Costly change orders
  - Increased project duration
- Time from inspection to construction can be long
  - Deterioration will have grown from last inspection
- NOT JUST FOR DECKS!




## What is really happening in the concrete?

Large Near surface Delamination

Extent of delamination beyond what sounding can pick up


Corrosion is active but has not formed enough iron oxide to create significant cracking



## How can we better understand these incipient deterioration conditions?



### **Concrete Deterioration**





## **Visual Inspection**


- Rust staining
- Cracking
- Spalls
- Exposed steel
- Water infiltration
- Efflorescence





## **Sounding Survey**


- Hammer sounding or chain drag
- Locates areas of large near surface delaminations
- Incipient delaminations cannot be identified
- False positives are rare
- False negatives are common





## **Corrosion Potential Measurements**


- ASTM C876 also known as half-cell potential
- Determines probability of active corrosion







### **Corrosion Potential – Bridge Deck**




of Uncoated Reinforcing Steel in Concrete


#### **Corrosion Potential – Bridge Substructure**



## **Corrosion Potential – Bridge Substructure**



Scale Per ASTM C876 Corrosion Potentials of Uncoated Reinforcing Steel in Concrete






## **Ground Penetrating Radar**


- Electromagnetic evaluation of concrete
  - Reinforcement layout
    - Location of embedded metals
  - Cover Depth
  - Qualitative condition of reinforced concrete
    - Chlorides, moisture, and concrete deterioration attenuate GPR signal







## **Cover Depth Survey**



- Cover depth is an important factor in the service life of a structure
  - Reduced cover depths allow for chlorides and carbonation to reach steel faster

$$C_{(x,t)} = C_o \left( 1 - erf \frac{x}{2\sqrt{D_c t}} \right)$$
$$t = \frac{1}{D_c} \left[ \frac{x}{2 \times inverf \left( 1 - \frac{C_{x,t}}{C_o} \right)} \right]^2$$






### **GPR Cover Survey of Bridge Columns**






#### **GPR Cover Survey of Bridge Columns**




Concrete Cover Depth (in)

#### GPR Amplitude Survey Poor Condition Fair Good Condition Bridge deck

GPR Amplitude (dB)











## Acoustic Methods – Surface Wave Velocity



Normal Compressional<br/>and Shear WaveLower Compressional Velocity<br/>and Lower or Loss of Shear Velocity ValuesVelocity Values








CURVE IS FOR THE RATIO: VSHEAR / V COMPRESSIONAL=0.55 WHICH IS EQUAL TO A POISSON'S RATIO OF 0.28





## **Deck Testing**





Deck delaminations impact echo measurements at sensor #1



3)

4)

Longitudinal partial deck cracking measurements at sensor #2



Longitudinal full deck cracking measurements at sensor #3

Transverse deck cracking measurements at sensor #4



### **Location of Delaminations**






#### **Substructure Testing**





#### **Bedanstin a tionits Foomp bas simp**act Repair Area **Schooling**






## **Infrared Thermography – Basic Theory**

- Delaminations have different thermal properties than sound concrete
  - Result of air-gap caused from the separation of the concrete
  - In the morning sun, delaminations heat up faster than sound concrete section
  - During evening cooling, delaminations cool down faster than sound concrete section
  - Allows for very quick assessment of large areas
  - Results are similar to chain drag and hammer sounding



### **IR – Equipment**







## **IR – 10th Avenue Bridge in Minneapolis**

- Hammer sounding survey done several years prior
- Wanted to know growth of deterioration from last survey
- IR provided a quick method to resurvey the concrete



Figure 2: Upstream: Arch Spalling under Spandrel Columns A (left) and B (right)



Figure 3: Upstream: Arch delaminations around pipe bracket and corners



Thank you!

## Questions?

